

# MeterView XL Programming Software

## Instruction Manual



*MeterView*® XL



**For use with the following Flow Rate/Totalizers:**

**ProtEX+**



PD6938-HA/ -EX / -IS  
Aluminum & Stainless Steel

**VantageView+**



PD6938-GP  
NEMA 4X Plastic

- Free PC-Based USB Programming Software
- Easy Programming of Feature-Packed Product
- USB Connection Provides Power to the Meter During Programming
- Save & Print Configuration Files without Meter Connected
- Micro USB Cable Provided with Meter
- Download the On-Board Data Log via USB or RS-485 Connection
- PC Data Logging for One or Multiple Variables

**PRECISION DIGITAL CORPORATION**

233 South Street • Hopkinton MA 01748 USA  
Tel (800) 343-1001 • (508) 655-7300

[www.predig.com](http://www.predig.com)

**PRECISION  
DIGITAL**

# MeterView XL Programming Software



The easiest and quickest way to program your pulse input rate/totalizers is with the free, PC-based, MeterView XL software. The rate/totalizer connects to the PC with a USB cable that also provides the power to the rate/totalizer during programming. Programming files can be saved for later use.


- Free PC-Based USB Programming Software
- Easy Programming of Feature-Packed Product
- USB Connection Provides Power to the Meter During Programming
- Save & Print Configuration Files without Meter Connected
- Micro USB Cable Provided with Meter
- PC Data Logging for One or Multiple Variables

## MeterView XL Software Installation


### ▲ IMPORTANT

- Please uninstall previous versions of this software prior to downloading, installing, and running the latest version.


1. Download MeterView XL Installation file to your PC from [www.predig.com/meterviewxl](http://www.predig.com/meterviewxl)
2. Locate the MeterView XL zipped folder on your PC and double-click to extract and open:




3. Double-click MeterView XL Windows Installer Package file to open:




4. The MeterView XL Setup Wizard window will appear. Click "Next" to start the installation process:




5. The MeterView XL License Agreement window appears next. Select "I agree" and click "Next" to continue the installation process:




- Choose the folder location where you would like the software to be installed to and select options for use. Then click “Next” to continue:




- Confirmation window will appear. Click “Next” to confirm the installation:



- The User Account Control message is displayed. Click “Yes” to proceed with the installation:



- Finally, the Installation Complete window will appear. Click “Close” to exit:




Now you are ready to open the MeterView XL software to begin programming your pulse input rate/totalizer.

## Connecting to the Computer

The rate/totalizer may be connected to any Windows 10 or Windows 11 PC via the provided USB cable by following these steps:

- Open the MeterView XL software.
- Connect the rate/totalizer to the PC with the provided USB cable.
- The software will ask if you would like to read the meter. Click OK.



## Specifications

<b>Availability</b>	Free download from <a href="http://www.predig.com/meterviewxl">www.predig.com/meterviewxl</a>
<b>System Requirements</b>	Microsoft® Windows® 10 & 11
<b>Communications</b>	USB 2.0 (Standard USB A to Micro USB B) Cable provided
<b>Configuration</b>	Configure all parameters on the meter. Configure meters one at a time.
<b>Configuration Files</b>	Generate with or without meter connected; Save to file for later use.
<b>USB Power Connection</b>	The meter is powered by the USB connection during programming. There is no need to apply external power. Note: The meter will not be damaged if external power is applied to it during programming.
<b>⚠ WARNING</b>	
The meter should only be connected to a computer while it is located in a safe area.	
<b>Compatibility</b>	Programs created for VantageView+ and ProtEX+ can be run on either meter. No other program sharing is permissible.
<b>USB Power Connection</b>	The meter is powered by the USB connection during programming. There is no need to apply external power. Note: The meter will not be damaged if external power is applied to it during programming.
<b>Data Logging Report</b>	The on-board data log can be downloaded via the USB or the RS-485 connection. Saved log file as “.csv” file format.
<b>PC Data Logging</b>	MeterView XL can be used data log directly to a computer connected to the meter via the USB or the RS-485 connection. The user can select what to log and at what interval. <ul style="list-style-type: none"> <li>• Rate</li> <li>• Total</li> <li>• Grand total</li> <li>• Open collector triggers</li> <li>• Relay triggers</li> <li>• Hold/Unhold outputs</li> </ul>
<b>Compatibility</b>	Programs created for VantageView+ and ProtEX+ can be run on either meter. No other program sharing is permissible.

# Using MeterView XL Software

## Main Screen

The main screen displays a real-time image of the connected meter and includes various information about this meter. This information includes max and min values, status of open collectors and relays (if option installed), and value of the input signal and output signal (if option installed). From the main screen the user can also operate the data logging feature and reset the max and min values.

## Main Programming


Click one of these buttons to navigate to a specific programming screen. The button will turn blue signifying the current programming screen.

## Meter Info


Shows the current model connected to the PC.

## Readings and Meter Status

Readings show what the meter is "reading" in labels set by and meaningful to the user. Meter status shows the input and output (if any) signal values, the status of the open collectors and relays (if any), and password setting.



## Edit Labels Button



Click the **Edit** button to enter or edit labels on the Main SW screen.

## Reset Button




Click the **Reset** button to reset the Maximum or Minimum values to zero.

## Relay Info Button



Click the **Relay Info** button to see the accumulated run time and cycle count of the relays (if relays installed).

## PC Data Logging Buttons



Click the **Setup** button to set the interval time for a PV and save the log file. Click the **start** or **pause** button to control the data logging.

## Meter Display

Shows the current value being displayed on the connected meter.

### Input / Scale Screen

The input / scale screen is used to configure the input signal and scale it appropriately using the multi-point linearization feature or using the k-factor scaling. The meter can be programmed to display rate and totals, in any available units using the display screen, without having to change the k-factor or the scaling points.


Function	This Meter
Set the input	Active pulse input
Low gate (Not visible)	1 second
High gate (Not visible)	2 seconds
Scale rate/PV	2 points
Units	Gallons/minute
K-factor	Disabled (Scale points and k-factor are exclusive of each other)

#### Input


Indicates the input to the meter is active pulse input.

#### Scale Input

These fields are used to select, scale unit, and scaling points for the rate/PV setup.




#### Unit Family & Scale Unit Menus




Select from a variety of scale units. The unit family is fixed to volume rate.

#### Time Base Menu



Select seconds, minutes, hours, or day for the rate.

#### Scaling Points / Import and Export



Select the number of scaling points. Up to 32 points can be entered.

The scaling points can be entered directly into the software or imported from a .csv file. They can also be exported to a .csv file.

#### K-Factor




Select the volume units and enter the k-factor value as specified on the flowmeter.

Click the  button at the bottom right of the window to send the new settings to the meter.


The following screen shows the pulse input type, low and high gate, and the k-factor being used.

Function	This Meter
Set the input	Active pulse input
Low gate	1 second
High gate	2 seconds
Scale rate/PV	Disabled
K-Factor	1.0 pulses/gallon



### Display Screen

The display screen is used to change what is displayed on the meter's **top** and **bottom** display lines. If either display lines are set to show units or tag, or to alternate between units, tags, and some other parameter, the tag shown, and the display time may be set in the **tag & units time** section. The **rate**, **total** and **grand total** sections are used for setting the units and decimal points. The **bargraph** section is used for selecting the source and scaling the bargraph value. The **backlight** section programs the meter to conserve power when it is powered from a battery. The backlight can be programmed to stay on for a certain amount of time after a period of front panel keys inactivity or be turned off entirely. The **LCD** section programs how long the LCD will stay on after a period of front panel keys inactivity.




### Toggle Display

The meter's dual-line display can be setup in multiple ways to provide an extremely informative view of the process variable being monitored. See the following example:


**Top Line:** Toggle Flow Rate and Rate Units  
**Bottom Line:** Toggle Total Flow and Total Units




**1**  
**Top Display**  
 Select what will be shown on the top line of the meter's display.




**2**  
**Tag & Units Time**  
 Enter name for custom tag and set display time for tag and units.




**3**  
**Bottom Display**  
 Select what will be shown on the bottom line of the meter's display. Activate "commas" to make it easier to read large numbers like 78,765,249.




**4**  
**Rate, Total & Grand Total**  
 Set units/sec, minute, hour, or day and set decimal point for rate, total, and grand total.



**5**  
**Bargraph**  
 Select the source and scaling for the bargraph.




**6**  
**Backlight / LCD**  
 Select a specific on time for the backlight and a specific sleep time for the LCD.



Click the  button at the bottom right of the window to send new settings to the meter.

### Open Collector Output Screen

The meter comes with two open collectors as a standard feature. The open collector output screen is used to program the open collector outputs for a specific output type (**pulse, alarm, timer, stopwatch**) or set to be **disabled**. The two open collectors may be programmed independently using the **output 1** and **output 2** sections. The following example shows the open collectors programmed for two **high alarms**. In addition, when an alarm occurs, the display is programmed to turn red, start to flash and display an alarm message.



Meter in the non-alarm condition.

#### Alarm Indicated by Flashing Red Display



Meter in alarm condition. Display turns red, flashes and shows HI FLOW alarm message.

Note: Flashing red display on alarm feature also available for relay outputs.

#### Output 1 and 2

Choose an output type, assign a function, and set other parameters for the selected function.

**1**

### Output Type Menu

Select an output type for the open collector output. In this case, alarm function.

**2**

### Alarm Function Menu

Assign the alarm function to PV1, PV2, or digital input.

**3**

### Reset Action Menu

Select the type of reset action.

**4**

### Set Parameters for the Function

Program set and reset points. Input a time for on and off delay. Select failsafe action, change the backlight to red upon alarm, and make the display flash.

**5**

### Custom Message

Check the box to have a message displayed on the meter. Input a custom message in the text field. The message will be displayed every 10 seconds. In this case, "HI FLOW".

Click the  button at the bottom right of the window to send new settings to the meter.



### Relay Output Screen

The meter can be equipped with two solid state relays as an option and these relays can be programmed to satisfy a wide variety of applications. The relay screen is used to program the relay outputs for a specific output type (**alarm, pump control, timer, stopwatch**) or set to be **disabled**. The two relays may be programmed independently using the **relay 1** and **relay 2** sections. The example below shows relays 1 and 2 programmed for batch control:

**1**

#### Output Type Menu

Select an output type for the relay output. In this case, batch.





The screenshot shows the 'relay output' window with two sections: 'relay 1' and 'relay 2'. Both are set to 'batch' output type. Relay 1 is configured with 'auto' batch function, preset 1000.0 GAL, max preset 10000.0 GAL, batch delay 120 sec, relay on delay 0 sec, and relay off delay 0 sec. Relay 2 is configured with 'preclose' batch function, preclose/preset 200.0 GAL, relay on delay 0 sec, and relay off delay 0 sec. Both have a custom message 'BATCH ON' or 'VAL2 ON' set to be displayed every 10 seconds. A 'CAUTION!' note is present: 'Function keys or digital input must be assigned to batch start/stop before sending configuration.'

**2**

#### Relay 1 Batch Function


Select auto or manual for the batch control. Select the batch value to count up or to count down. Enter a preset value and max preset value. Enter a time for batch delay, relay on delay, and relay off delay.



**3**

#### Relay 2 Batch Function

Select preclose or preset for the batch control. Enter a preclose/preset value. Enter a time for relay on delay and relay off delay.



**4**

#### Custom Message

A custom message may be displayed on the meter when the relay is active by checking 'message' box. The message, "BATCH ON", in this case, will be displayed every 10 seconds.



Click the  button at the bottom right of the window to send new settings to the meter.

### 4-20 mA Output Screen


The 4-20 mA out screen allows the optional 4-20 mA analog output to be set up and scaled appropriately. The output may either be scaled independently of the input, or simply retransmitted in the same scale. In addition, analog output values can be set for under and overrange input conditions.

#### Analog Output Source

This section is used for scaling the output to a new range or retransmitting the existing values.

#### Output Values for Input Under and Overrange


Overrange and underrange values determine what mA signal the meter will output if the the display is underrange or overrange. This value may be set to 1 mA, 3.5 mA, 3.8 mA, 20.5 mA, 20.8 mA, 23 mA, or disabled.



1

#### Analog Output Source Menu


Select a source for the 4-20 mA output: rate, total, or disabled.



2

#### Scale Values

Enter the scale values for display 1, output 1, display 2, and output 2.



3

#### Underrange Menu


Select the output value for when the display value is underrange. This can also be disabled.



4

#### Overrange Menu

Select the output value for when the display value is overrange. This can also be disabled.



**Note:** The “input condition definitions” are not applicable to pulse input meter.

Click the  button at the bottom right of the window to send new settings to the meter.

### Advanced Screen

The advanced screen provides a way to change the meter settings that are rarely changed for most applications. The **cutoff**, and **filter** values can normally be left alone and should only be changed if there is an unsteady or noisy process signal. The **function keys / digital input** section is used to set the actions that the three front panel function keys and the digital input will perform. The **total settings** section is used to set the total and grand total reset mode, total with 8 or 13 digits limit, and the initial total value. The **data log setup** section is used to set what to log and when: event log, log day & time, log at time interval, log based on hourly or daily schedule, log continuously or stop when full, download the log to a PC, and erase the log in the meter internal memory.

**1**  
**Cutoff and Filter**  
**Cutoff:** Point below at which display always shows zero.  
 Most commonly used with differential pressure transmitters to zero out the often unsteady reading at low flow rates.


**Filter:** Used for applications where the meter is set up to count pulses generated by switch contacts.

- Disable: Greater than 100 kHz (no filter)
- Fast: 1,000 Hz
- Medium: 240 Hz
- Slow: 100 Hz




### Function Keys / Digital Input

**2** This section is used for programming the front panel function keys and digital input, if connected. Select an action for each of the front panel keys of the meter; F1, F2, F3, and an action for the digital input, if connected. Below is the full list of available actions that can be set for the function keys and digital inputs.




Click the  button at the bottom right of the window to send new settings to the meter.

Advanced Screen Continued




3




**Total Settings**

This section is used for programming the total and grand total reset. Check manual to be able to reset the total manually. Select a total limit and/or grand total limit to 8 digits or 13 digits. If enabled, an initial value can be entered for both the total and grand total. Grand total reset can also be enabled or disabled and a non-resettable GT can be selected.



4



**Data Log Setup**

This section is used for setting the log time and log time interval. Clicking the event log button allows for setting up the data log to capture activities for the total reset, grand total reset, hold/unhold, open collector 1 & 2, and relay 1 & 2.



Clicking the schedule button will allow for setting the data log to run on an hourly or daily basis.

The data log can be set to run continuously or to stop when full. The data from the log can be downloaded by clicking the download log button or it can be erased by clicking the erase log button.

Click the  button at the bottom right of the window to send new settings to the meter.

### System Screen



The system screen shows basic meter information such as software number and revision level. It also provides a means to set a password, set the meter date & time, set the battery saving features, reset the meter to factory defaults, set a system tag, and the Modbus serial settings. The system tag is a custom message that appears on meter power up (8 characters max).

**1 SFT/Firmware Version**  
 This section shows the current software (firmware) number and version. The system tag may be changed to display a custom message on power up (8 characters max).

**2 Password**  
 This section is used for setting a password which protects the meter from unauthorized changes of the settings. A password can be set for the main software settings and also for the total reset and GT reset settings. Click the change button to change the password. Enter characters in the text field.




**3 Set Time**  
 Use the dropdown menus to select the date and time.



**4 Battery Settings**  
 Select to show battery indicator, safe-touch buttons delayed, and sensor power. Set the RS-485 on battery to always on or disable. A time interval can also be set for the battery in hours, minutes, and seconds.

**5 Factory Defaults Reset Button**  
 Click the reset button to restore all meter settings to their factory defaults.



**6 Meter Serial Settings**  
 Enter a name for the Modbus tag, select the slave ID, baud rate, and parity. Also enter a time for the transmit delay in milliseconds.

### Data Logging File

The log file is saved in .csv file format and it contains all the information selected in the data log setup.

- Information header
- Date & time
- Log sequence
- Log source
- Rate, total, and grand total with units
- Alarm state
- Open collector and relay state

	A	B	C	D	E	F	G	H	I	J	K	L	M	N
1	Meter Model	PD6938	Firmware	1	MeterView	2.1.0	Download Time	April 18 2023 10:59 AM						
2	Date	Time	Sequence	Source	Rate	Rate Units	Total	Total Unit	Grand Total	Grand Total Units	OC1	OC2	Relay1	Relay2
3														
4	Apr/18/2023	10:17:57	1	OC1	100	GAL/sec	6053	GAL	6053	GAL	Alarm On	Alarm On	On	Off
5	Apr/18/2023	10:17:57	1	OC2	100	GAL/sec	6053	GAL	6053	GAL	Alarm On	Alarm On	On	Off
6	Apr/18/2023	10:17:57	1	Rly1	100	GAL/sec	6053	GAL	6053	GAL	Alarm On	Alarm On	On	Off
7	Apr/18/2023	10:18:00	2	Interval	100	GAL/sec	6353	GAL	6353	GAL	Alarm On	Alarm On	On	Off
8	Apr/18/2023	10:18:07	3	Rly1	64	GAL/sec	6975	GAL	6975	GAL	Alarm On	Alarm On	Off	Off
9	Apr/18/2023	10:18:09	4	OC2	26	GAL/sec	7028	GAL	7028	GAL	Alarm On	OC2 Off	Off	Off
10	Apr/18/2023	10:18:12	5	OC1	10	GAL/sec	7067	GAL	7067	GAL	OC1 Off	OC2 Off	Off	Off
11	Apr/18/2023	10:18:35	6	OC1	36	GAL/sec	7347	GAL	7347	GAL	Alarm On	OC2 Off	Off	Off
12	Apr/18/2023	10:18:36	7	OC2	45	GAL/sec	7398	GAL	7398	GAL	Alarm On	Alarm On	Off	Off
13	Apr/18/2023	10:18:47	8	Rly1	60	GAL/sec	8022	GAL	8022	GAL	Alarm On	Alarm On	On	On
14	Apr/18/2023	10:18:47	8	Rly2	60	GAL/sec	8022	GAL	8022	GAL	Alarm On	Alarm On	On	On
15	Apr/18/2023	10:18:57	9	Rly1	60	GAL/sec	8622	GAL	8622	GAL	Alarm On	Alarm On	Off	Off
16	Apr/18/2023	10:18:57	9	Rly2	60	GAL/sec	8622	GAL	8622	GAL	Alarm On	Alarm On	Off	Off
17	Apr/18/2023	10:19:00	10	Interval	60	GAL/sec	8802	GAL	8802	GAL	Alarm On	Alarm On	Off	Off
18	Apr/18/2023	10:19:21	11	Rly1	60	GAL/sec	10062	GAL	10062	GAL	Alarm On	Alarm On	On	Off
19	Apr/18/2023	10:19:31	12	Rly1	60	GAL/sec	10662	GAL	10662	GAL	Alarm On	Alarm On	Off	Off
20	Apr/18/2023	10:19:54	13	Rly1	60	GAL/sec	12041	GAL	12041	GAL	Alarm On	Alarm On	On	On
21	Apr/18/2023	10:19:54	13	Rly2	60	GAL/sec	12041	GAL	12041	GAL	Alarm On	Alarm On	On	On
22	Apr/18/2023	10:20:00	14	Interval	60	GAL/sec	12401	GAL	12401	GAL	Alarm On	Alarm On	On	On
23	Apr/18/2023	10:20:04	15	Rly1	60	GAL/sec	12641	GAL	12641	GAL	Alarm On	Alarm On	Off	Off
24	Apr/18/2023	10:20:04	15	Rly2	60	GAL/sec	12641	GAL	12641	GAL	Alarm On	Alarm On	Off	Off
25	Apr/18/2023	10:20:27	16	Rly1	60	GAL/sec	14021	GAL	14021	GAL	Alarm On	Alarm On	On	Off
26	Apr/18/2023	10:20:37	17	Rly1	60	GAL/sec	14621	GAL	14621	GAL	Alarm On	Alarm On	Off	Off
27	Apr/18/2023	10:21:00	18	Interval	60	GAL/sec	16001	GAL	16001	GAL	Alarm On	Alarm On	On	On
28	Apr/18/2023	10:21:01	19	Rly1	60	GAL/sec	16061	GAL	16061	GAL	Alarm On	Alarm On	On	On
29	Apr/18/2023	10:21:01	19	Rly2	60	GAL/sec	16061	GAL	16061	GAL	Alarm On	Alarm On	On	On
30	Apr/18/2023	10:21:11	20	Rly1	60	GAL/sec	16661	GAL	16661	GAL	Alarm On	Alarm On	Off	Off
31	Apr/18/2023	10:21:11	20	Rly2	60	GAL/sec	16661	GAL	16661	GAL	Alarm On	Alarm On	Off	Off
32	Apr/18/2023	10:21:34	21	Rly1	60	GAL/sec	18041	GAL	18041	GAL	Alarm On	Alarm On	On	Off
33	Apr/18/2023	10:21:44	22	Rly1	60	GAL/sec	18641	GAL	18641	GAL	Alarm On	Alarm On	Off	Off
34	Apr/18/2023	10:22:00	23	Interval	60	GAL/sec	19601	GAL	19601	GAL	Alarm On	Alarm On	Off	Off
35	Apr/18/2023	10:22:07	24	Rly1	60	GAL/sec	20021	GAL	20021	GAL	Alarm On	Alarm On	On	On
36	Apr/18/2023	10:22:07	24	Rly2	60	GAL/sec	20021	GAL	20021	GAL	Alarm On	Alarm On	On	On
37	Apr/18/2023	10:22:17	25	Rly1	60	GAL/sec	20621	GAL	20621	GAL	Alarm On	Alarm On	Off	Off

**▲ IMPORTANT**

- The function keys and the digital input can be used to log manually at any time.

### Configuration File

A configuration file can be generated with or without a meter connected to the PC. This makes it possible to prepare meter configurations prior to having the meter in hand. Meter configurations can be saved and re-loaded into other meters. Meter configurations can also be printed:

```

Meter Configuration                               Date: 04/27/2023
PD6938                                             Software ID: SFT133 Revision: 1.000
System tag                                         FLOW 1
Printed by MeterView XL                           Version 2.1.0

-- Input --
input active
low gate 1
low gate 2
total enable

k-factor 1.00001 pulses / unit

PV1 function linear
PV1 units family vol rate
PV1 units GAL
PV1 time base sec
PV1 scale points 2
PV1 scale input display
0 0
10000 10000

-- Display --
top display RATE
lower display TOTAL
custom tag RATE 1
tag time 3 sec
units time 3 sec
commas enable

Rate display units GAL
Rate time base sec
Rate decimal point 00000000

Total display units GAL
Total multiplier 1
Total decimal point 00000000

GTotal display units GAL
GTotal multiplier 1
GTotal decimal point 00000000

bargraph source RATE
bargraph 0% 0
bargraph 100% 100
    
```

```

backlight 10 seconds
LCD 10 minutes

-- Open Collector --
OC1 output type alarm
OC1 source rate
OC1 reset action automatic
OC1 set point 90 GAL/sec
OC1 reset point 80 GAL/sec
OC1 on delay 0 sec
OC1 off delay 0 sec
OC1 fail safe disable
OC1 red backlight enable
OC1 flash display enable
OC1 message enable HI ALRM

OC2 output type pulse
OC2 source rate
OC2 factor 0.010000
OC2 message enable disable OC 2 ON

-- Relay --
relay 1 output type sample
relay 1 sample mode total
relay 1 sample count 1000 GAL
relay 1 sample time 10 sec
relay 1 message enable disable RLY1 ON

relay 2 output type alarm
relay 2 source total
relay 2 reset action automatic
relay 2 set point 100000 GAL
relay 2 on delay 0 sec
relay 2 off delay 0 sec
relay 2 fail safe disable
relay 2 red backlight enable
relay 2 flash display enable
relay 2 message enable T ALARM

-- mA Output --
analog output source RATE
analog output scale display output
0 4.000
100 20.000
    
```

```

analog output underrange 3.8 mA
analog output overrange 20.5 mA

-- Advanced --
cutoff enable enable
cutoff 0
filter Off
bypass 0.4

total reset enable enable
total limit 8-digit
total reset clock day time
Week day 08:00 hh:mm
Thursday 12:00 hh:mm
Friday 16:00 hh:mm
Every day 00:00 hh:mm

grand total reset enable disable
grand total limit 8-digit

function key 1 display
function key 2 reset
function key 3 acknowledge all alarms
digital input reset total

-- meter log --
log wrap on
log time
log time 1 Every day 00:00
log time 2 Monday 08:00
log time 3 Tuesday 16:00
log time 4 Wednesday 20:00
events
total reset on
grand total reset on
hold / unhold off
open copollector 1 on
open copollector 2 on
relay 1 on
relay 2 on
log interval on 00:01:00 hh:mm
schedule hourly daily

-- battery --
    
```

```

battery indicator off
safe touch off
sensor power off
RS-485 on battery

-- RS485 --
Modbus tag MBUS TAG
slave ID 1
baud rate 9600
parity even
transmit delay 10
    
```

## Contact Precision Digital

### Technical Support

Call: (800) 610-5239 or (508) 655-7300

Email: [support@predig.com](mailto:support@predig.com)

### Sales Support

Call: (800) 343-1001 or (508) 655-7300

Email: [sales@predig.com](mailto:sales@predig.com)

### Place Orders

Email: [orders@predig.com](mailto:orders@predig.com)

For the latest version of this manual please visit

[www.predig.com](http://www.predig.com)

### PRECISION DIGITAL CORPORATION

233 South Street • Hopkinton MA 01748 USA

Tel (800) 343-1001 • (508) 655-7300

[www.predig.com](http://www.predig.com)

